, _	U 4→2/±0		ネジウ	で寸法	Ī												
メーカー	サイズ(型)	型式	W	Н	TV-PL3	CR-PL6N	CR-PL7	CR-PL11N	TV-PL12K	CR-PL13N	CR-PL14N	CR-PL16N	CR-PLKG1	CR-PLKG2	CR-PLKG3	YK-PLKG5	YK-PLKG6
		LC-52AE6	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52AE60	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52AE7	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52DS6	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52DX1	400	400	×	0	××	0	× :X	× ::	0	0	× ×	× ::	0	× ::	0
		LC-52DX2	400	400	×	0	×	0	× ×	× ×	0	0	×	× ×	0	× ::	0
		LC-52DX3	400	400	×	0	××	Ö	×	× ×	0	Ö	× ×	× ×	Ö	× ::	0
		LC-52DZ3	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52ES50	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52EX5	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52F5	_	_	×	×	×	×	×	×	×	×	×	×	×	×	×
		LC-52G7	400	400	0	0	0	0	×	×	0	0	0	×	0	0	0
		LC-52G9	400	400	0	0	0	0	×	×	0	0	0	×	0	0	0
		LC-52GX1W	200	200	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52GX2W	200	200	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52GX35	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52GX3W	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52GX45	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52GX4W	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52GX5	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
	52	LC-52L5	400	400	×	×	×	×	×	×	×	×	×	×	×	×	×
	32	LC-52LB3	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52LV3	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52LX1	400	400	0	0	0	0	×	×	0	0	0	×	0	×	0
		LC-52LX3	400	400	Q	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52RX1W	400	400	0	0	0	Q	0	×	0	0	0	×	0	×	0
		LC-52RX5	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52SE1	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52UD20	400	400	O O	Ŏ	<u> </u>	Ŏ	0	X	O O	O O	0	X	O O	X	0
		LC-52US20	400	400	0	0	$\stackrel{\triangleright}{\sim}$	<u> </u>	Ö	X	0	O O	0	X	O O	X	0
		LC-52V5	400	400	0	0	<u> </u>	Ŏ	×	X	0	0	0	X	<u> </u>	X	0
		LC-52XF3	400	400	0	<u> </u>	<u> </u>	0	Ő	X	0	0	<u> </u>	X	0	X	0
		LC-52XL9	400	400	0	0	0	0	×	×	0	0	0	×	0	×	0
		LC-52XL10 LC-52XL20	400 400	400 400	0	00		0	ô	×	0	0	0	×	0	×	0
		LC-52XS1	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-52W9	400	400	ŏ	Ö	0	Ö	×	×	ŏ	Ö	0	×	Ö	×	ŏ
		LC-52W10	400	400	ŏ	ŏ	<del>  0</del>	Ö	×	×	ŏ	ŏ	ŏ	×	ŏ	×	ŏ
		LC-52Z5	400	400	ŏ	ŏ	ŏ	Ö	Ô	×	Ö	Ö	Ö	×	ŏ	×	Ö
			400	700				-			_	_			_		
		PN-E521	200	200	0	0	0	0	0	×	0	0	0	×	0	×	0
		PN-S525	400	200	0	0	0	0	0	×	0	0	0	×	0	×	0
	F.	LC-50U20	400	400	ŏ	ŏ	T	Ö	×	×	ŏ	ŏ	ŏ	×	ŏ	×	ŏ
	50	LC-50W20	400	400	Ö	Ö	1	Ö	×	×	Ö	Ö	Ö	×	Ö	×	Ö
		PN-E471	400 200	200	0	0	0	0	0	×	0	0	0	×	0	×	0
	47	PN-E471R	400		0	0	0	0	0	×	0	0	0	×	0	×	0
	''		200	200													
		PN-U473	400	200	0	0	0	0	0	×	0	0	0	×	0	×	0
		PN-Y475	400 300	400 300	0	0	0	0	0	×	0	0	0	×	0	×	0
		LB-T461 LC-46AE6	400	400	0	00	0	0	0	×	0	0	0	×	0	×	0
		LC-46AE7	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-46DS6	400	400	0	0	0	0	0	×	0	0	00	×	0	×	0
		LC-46DX1	400	400	× *:	Ö	× **	Ö	× *:	× **	ŏ	Ö	× **	× **	ŏ	××	ŏ
I	1	LO TODAT	700	700	^ ^				·· /\	· · ·			· · ·	^ ^		^ ^	

.,	TT 1 - 2 / TH		ネジウ	で寸法	1												
メーカー	サイズ(型)	型式	W	Н	TV-PL3	CR-PL6N	CR-PL7	CR-PL11N	TV-PL12K	CR-PL13N	CR-PL14N	CR-PL16N	CR-PLKG1	CR-PLKG2	CR-PLKG3	YK-PLKG5	YK-PLKG6
		LC-46DX2	400	400	× ::	0	× :X	0	× *	× *	0	0	× ×	× ×	0	× *:	0
		LC-46DX3	400	400	× ::	0	×	0	× ×	× *	0	0	× *	× ×	0	× *	0
		LC-46DZ3	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-46ES50	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-46EX5	400	400	0	Ö	0	0	0	×	0	0	0	×	0	×	0
		LC-46F5	_	_	×	×	×	×	×	×	×	×	×	×	×	×	×
		LC-46G7	400	400	0	0	0	0	×	×	0	0	0	×	0	0	0
		LC-46G9	400	400	0	0	0	0	×	×	0	0	0	×	0	0	0
		LC-46GX1W	200	200	Ŏ	Ö	Ö	Ö	0	×	Ö	Ö	Ö	×	Ö	×	Ö
		LC-46GX2W	200	200	Ŏ	Ŏ	Ŏ	Ö	Ö	×	Ŏ	Ŏ	Ö	×	Ö	×	Ŏ
		LC-46GX35	400	400	Ŏ	Ŏ	Ŏ	Ö	Ö	×	Ŏ	Ö	Ö	×	Ö	×	Ö
		LC-46GX3W	400	400	Ŏ	Ö	Ŏ	Ö	Ö	×	Ö	Ö	Ö	×	Ö	×	Ö
		LC-46GX45	400	400	Ŏ	Ŏ	Ŏ	Ö	Ŏ	×	Ŏ	Ŏ	Ŏ	×	Ŏ	×	Ŏ
		LC-46GX4W	400	400	ŏ	ŏ	ŏ	ŏ	ŏ	×	Ŏ	ŏ	ŏ	×	Ŏ	×	Ŏ
	46	LC-46GX5	400	400	Ŏ	Ŏ	Ŏ	Ŏ	ŏ	×	Ŏ	Ŏ	Ö	×	Ŏ	×	Ö
		LC-46L5	400	400	×	×	×	×	×	×	×	×	×	×	×	×	×
		LC-46LB3	400	400	Ô	Ô	Ô	Ô	Ô	×	Ô	Ô	Ô	×	Ô	×	Ô
		LC-46LV3	400	400	ŏ	ŏ	ŏ	Õ	ŏ	×	ŏ	ŏ	ŏ	×	ŏ	×	ŏ
		LC-46LX1	400	400	ŏ	Ö	ŏ	Ö	×	×	Ö	ŏ	Ö	×	ŏ	×	Ö
		LC-46LX3	400	400	ŏ	Ö	Ö	0	0	×	Ö	ŏ	Ö	×	ŏ	×	Ö
		LC-46RX1W	400	400	ŏ	ŏ	ŏ	Õ	ŏ	×	ŏ	ŏ	ŏ	×	ŏ	×	ŏ
		LC-46RX5	400	400	ŏ	ŏ	ŏ	ŏ	ŏ	×	ŏ	ŏ	ŏ	×	Ö	×	ŏ
		LC-46SE1	400	400	ŏ	ŏ	l ö	Ö	Ö	×	Ö	Ö	Ö	×	Ö	×	Ö
		LC-46V5	400	400	ŏ	Ö	ŏ	$\frac{\circ}{\circ}$	×	×	Ö	Ö	Ö	×	Ö	×	Ö
		LC-46V7	400	400	ŏ	ŏ	<del>  0</del>	ŏ	×	×	ŏ	ŏ	ŏ	×	ŏ	×	ŏ
		LC-46XF3	400	400	ŏ	ŏ	Ö	ŏ	Ô	×	ŏ	ŏ	ŏ	×	ŏ	×	ŏ
		LC-46XJ1	300	300	ŏ	ŏ	l ö	Ö	Ö	×	Ö	Ö	Ö	×	Ö	×	Ö
		LC-46XL9	400	400	ŏ	ŏ	0	$\frac{\circ}{\circ}$	×	×	Ö	Ö	0	×	0	×	Ö
		LC-46XL10	400	400	ŏ	ŏ	0	Ö	×	×	ŏ	Õ	ŏ	×	Ö	×	ŏ
		LC-46XL20	400	400	ŏ	ŏ		ŏ	Ô	×	ŏ	ŏ	ŏ	×	ŏ	×	ŏ
		LC-46W9	400	400	ŏ	ŏ	0	$\frac{\circ}{\circ}$	×	×	Ö	Ö	Ö	×	Ö	×	Ö
		LC-46W10	400	400	ŏ	Ö	ŏ	$\frac{\circ}{\circ}$	×	×	Ö	Ö	Ö	×	Ö	×	Ö
		LC-46Z5	400	400	ŏ	ŏ	<del>  0</del>	ŏ	Ô	×	ŏ	ŏ	ŏ	×	ŏ	×	ŏ
		PN-465	400	200	ŏ	ŏ	<del>  0</del>	ŏ	ŏ	×	ŏ	ŏ	ŏ	×	ŏ	×	ŏ
		LC-45AE5	-	-	-	-	-		-	_	-	_		_	_	_	-
		LC-45BE1W	200	200	0	0	0	0	0	×	0	0	0	×	0	×	0
	45	LC-45BE1W	200	200	ŏ	Ö	<del>  0</del>	$\frac{\circ}{\circ}$	0	×	Ö	Ö	0	×	Ö	×	Ö
	45	LC-45BE2W LC-45GD1	200		_	-	<del>  -</del>		-	×	_	_	-	×		×	_
		LC-45GE2	_	_	_	_	<del>  _</del>		_	×	_	_	_	×	_	×	_
		LC-43GE2	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-42DS5	400	400	0	0	<del>  0</del>	0	0	×	0	0	00	×	0	×	0
		LC-42DS6	400	400	0	0	<del>  0</del>	0	0	×	0	0	00	×	0	×	0
		LC-42DX1	400	400	× ::	Ö	× **	$\frac{\circ}{\circ}$	× *:	×.*	Ö	Ö	× *:	× *	Ö	××	Ö
		LC-42ES50	400			- i			_				_				
		LC-42EX5	400	400 400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-42GX1W	200	200	0	0	0	0	0	×	0	0	00	×	0	×	0
		LC-42GX1W LC-42GX2W	200	200	8				0	×	0		00	×		×	0
		LC-42GX2W	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
	42	LC-42GX3W LC-42GX4W	400	400	0	0	8	0	0	×	0	0	0	×	0	×	0
		LC-42GX4W LC-42GX5	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-42GX5 LC-42RX1W	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
					0		0	0				0		×	0	×	
		LC-42XJ1 PN-425	300	300		0	8	0	0	×	0	0	0			×	0
		FIN-420	400 100	200 200	0	0		-	0	_ ^	0			×	0	^	0
		PN-E421	400	200	0	0	0	0	0	×	0	0	0	×	0	×	0
I	I		400	200	1	l	1			l	l	I .		l	l		

, _	U /-*/#II	#11_#	ネジ穴	寸法	1												
メーカー	サイズ(型)	型式	W	Н	TV-PL3	CR-PL6N	CR-PL7	CR-PL11N	TV-PL12K	CR-PL13N	CR-PL14N	CR-PL16N	CR-PLKG1	CR-PLKG2	CR-PLKG3	YK-PLKG5	YK-PLKG6
		PN-U423	400	200	0	0	0	0	0	×	0	0	0	×	0	×	0
		PN-Y425	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LB-T401	200	200	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-40AE6	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-40AE7	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
シャープ		LC-40BH11	100	100	0	0	0	0	0	×	0	0	0	×	0	×	0
ノヤーノ		LC-40DS6	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-40DR3	300	300	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-40DR9	_	-	×	×	×	×	×	×	×	×	×	×	×	×	×
		LC-40DX2	400	400	×	0	×	0	××	××	0	0	××	××	0	×	0
		LC-40DX3	400	400	×	0	×	0	× ×	× ×	0	0	××	× ×	0	× ×	0
		LC-40DZ3	300	300	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-40E9	_	-	×	×	×	×	×	×	×	×	×	×	×	×	×
		LC-40F3	200	200	×	×	×	×	×	×	×	×	×	×	×	×	×
		LC-40F5	200	200	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-40G7	300	300	0	0	0	0	×	×	0	0	0	×	0	0	0
		LC-40G9	300	300	0	0	0	0	×	×	0	0	0	×	0	0	0
	40	LC-40H7	300	300	0	0	0	0	×	×	0	0	0	×	0	×	0
		LC-40H9	300	300	0	0	0	0	×	×	0	0	0	×	0	×	0
		LC-40H11	100	100	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-40H20	100	100	0	<u> </u>		0	×	0	0	0	0	0	0	0	0
		LC-40J9	300	300	0	0	0	0	×	×	0	0	×	×	0	×	×
		LC-40J10	300	300	0	0	0	0	×	×	0	0	×	×	0	×	×
		LC-40L5	300	300	X	X	X	×	×	×	×	×	×	×	×	×	×
		LC-40LV3	300	300	0	<u> </u>	0	0	0	×	0	0	0	×	Q	×	0
		LC-40LX1	400	400	0	<u> </u>	0	0	×	×	0	0	0	×	0	×	0
		LC-40LX3	300	300	0	<u> </u>	0	0	0	×	0	0	0	×	0	×	0
		LC-40SE1	300	300	0	<u> </u>	<u> </u>	0	0	X	<u> </u>	0	0	X	0	X	Ŏ
		LC-40R5	300	300	0	<u> </u>	0	<u> </u>	X	X	0	0	0	X	0	X	Ŏ
		LC-40U20 LC-40V5	200 300	200 300	0	<u> </u>		0	×	×	0	0	0	×	0	×	0
		LC-40V7	300	300	0	0	0	0	×	×	0	0	00	×	0	×	0
		LC-40V7 LC-40Z5	300	300	Ö	$\frac{0}{0}$	0	C	ô	×	Ö	0	0	×	0	×	0
		LC-32AD5	- 300	-	_		_		_					^		_	
		LC-37AD1	_		_		_	_	_	×				×		×	<u> </u>
		LC-37AD2	_	_	_		_		_	×				×		×	
		LC-37AD5	_	_	_	_	_	_	_	×	_			×		×	
		LC-37BD1W	200	200	0	0	0	Ο	0	×	0	0	0	×	0	×	0
		LC-37BD2W	200	200	Ö	Ö	ŏ	ŏ	ŏ	×	Ö	ŏ	Ö	×	ŏ	×	ŏ
		LC-37DS3	300	300	Ö	Ö	Õ	Õ	Õ	×	Ö	Õ	Ö	×	Ŏ	×	Ö
		LC-37DS5	300	300	Ŏ	Ŏ	Ŏ	Ö	Ŏ	×	Ŏ	Õ	Ö	×	Ŏ	×	Ŏ
		LC-37DX1	300	300	× :X	Ö	× :X	Ö	× ×	× ×	Ŏ	Ŏ	× ×	× ×	Ŏ	× *	Ŏ
		LC-37ES50	400	400	0	Ŏ	O	Ö	O O	×	Ö	Ö	0	×	Ö	×	Ö
		LC-37EX5	400	400	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-37G300	_	-	-	-	_	_	_	×	_	_	-	×	_	×	_
		LC-37G700	-	_	-	-	-	-	-	×	_	_	-	×	-	×	-
		LC-37GD1	-	_	-	-	-	_	-	×	_	_	_	×	-	×	-
		LC-37GD2	-	-	_	_	_	-	_	×	_	_	ı	×	_	×	-
	37	LC-37GD3	_	-	-	-	-	-	_	×	-	_	-	×	_	×	-
		LC-37GD4	_	-	-	-	-	-	_	×	-	_	-	×	_	×	-
		LC-37GD6	_	_	-	_	-	_	_	×	-	_	-	×	_	×	-
		LC-37GD7	_	-	_	-	-	-	_	×	-	_	-	×	_	×	-
		LC-37GE2	_	-	-	-	-	-	_	×	-	_	1	×	-	×	-
		LC-37GH1	200	200	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-37GH2	200	200	0	0	0	0	0	×	0	0	0	×	0	×	0

,	<b>/ →</b> °/≖il	TI	ネジグ	で寸法													
メーカー	サイズ(型	型式	W	H	TV-PL3	CR-PL6N	CR-PL7	CR-PL11N	TV-PL12K	CR-PL13N	CR-PL14N	CR-PL16N	CR-PLKG1	CR-PLKG2	CR-PLKG3	YK-PLKG5	YK-PLKG6
		LC-37GS10	200	200	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-37GS20	200	200	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-37GX1W	200	200	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-37GX2W	200	200	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-37GX3W	300	300	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-37GX4W	300	300	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-37GX5	300	300	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-37XJ1	300	300	0	0	0	0	0	×	0	0	0	×	0	×	0
		PN-371	200	200	0	0	0	0	0	×	0	0	0	×	0	×	0
		LC-32BD1	200	200	0	0	0	0	0	0	0	0	0	0	0	0	0
		LC-32BD2	200	200	0	0	0	<u> </u>	0	0	0	0	0	0	0	0	0
		LC-32BH11	100	100	0	0	0	0	0	0	0	0	0	0	0	0	0
		LC-32D10	-		-	-	-		-							-	
		LC-32D30	200	200	0	0	0	<u> </u>	0	0	0	0	0	0	0	0	0
		LC-32DE5	200	200	0	0	0	<u> </u>	0	0	0	0	0	0	0	0	0
		LC-32DH6	200	200	Ŏ	Ŏ	Ŏ	<u> </u>	Ŏ	<u> </u>	<u> </u>	Ŏ	<u> </u>	Ŏ	Ŏ	Ŏ	0
		LC-32DS1	200	200	<u> </u>	0	<u> </u>	<u> </u>	0	<u> </u>	0	0	<u> </u>	0	0	<u> </u>	0
		LC-32DS3	300	300	0	0	O O	<u> </u>	Ŏ	0	0	O O	0	0	0	<u> </u>	0
		LC-32DS5	300	300	0	0	0	<u> </u>	0	0	0	0	0	0	0	0	0
		LC-32DS6	400	400	0	0	0	<u> </u>	0	0	0	0	0	0	0	0	0
		LC-32DR3	200	<u>200</u> –	O ×	×	×	<u> </u>	×	×	×	O ×	×	×	O ×	O ×	×
		LC-32DR9 LC-32DX1	200	200	× *	×	× **	×	× **	×	×	×	× *	×	×	×	×
		LC-32DX1	200	200	× ×	ô	× **	ô	* *	Ô	ô	ô	× **	ô	ô	Ô	ô
		LC-32DX3 LC-32DZ3	200	200	0	0	0	$\frac{\circ}{\circ}$	0	00	0	0	0	0	Ö	0	0
		LC-32E5	200	200	ŏ	Ö	Ö	<del></del>	Ö	00	Ö	Ö	00	Ö	Ö	Ö	Ö
		LC-32E6	200	200	ŏ	ŏ	ŏ	$\frac{\circ}{\circ}$	Ö	00	Ö	ŏ	0	Ö	Ö	Ö	Ö
		LC-32E7-B	200	200	ŏ	Ö	ŏ	<del></del>	ŏ	Ô	ŏ	Ö	Ô	Ö	Ô	ŏ	Ö
		LC-32E8-B	200	200	ŏ	Õ	ŏ	Ö	ŏ	Ö	ŏ	ŏ	$\overset{\circ}{\circ}$	ŏ	ŏ	ŏ	ŏ
		LC-32E9	-	_	×	×	×	×	×	×	×	×	×	×	×	×	×
		LC-32F3	200	200	×	×	×	×	×	×	×	×	×	×	×	×	×
		LC-32F5	200	200	0	0	0	0	0	0	0	0	0	0	0	0	0
		LC-32G300	_	-	_	-	-	_	_	-	_	_	_	_	_	Ĭ -	_
		LC-32G700	-	-	_	-	_	_	_	_	-	_	_	-	_	-	-
		LC-32GD1	-	-	-	-	_	-	-	-	-	-	-	-	-	-	-
		LC-32GD2	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
		LC-32GD3	_	-	-	-	_	_	_	ı	_	_	ı	-	_	-	-
	32	LC-32GD4	-	-	-	-	-	-	_	-	-	_	_	-	-	-	-
	32	LC-32GD6	-	-	-	-	_	-	_	ı	_	_	_	-	_	-	_
		LC-32GD7	-	-	-	-	_	_	-	-	-	-	_	-	-	_	-
		LC-32GH1	_	_	_	-	_		_		_	_		_	_		_
		LC-32GH2	200	200	0	0	0	0	0	0	0	0	0	0	0	0	0
		LC-32GH3	300	300	0	0	0	<u> </u>	0	0	0	0	0	0	0	0	0
		LC-32GH4	300	300	Ö	Ö	Ö	<u> </u>	0	0	0	0	0	0	0	0	0
		LC-32GH5	200	200	0	0	0	<u> </u>	0	0	0	0	0	0	0	0	0
		LC-32GS10	200	200	O O	<u> </u>	Ŏ	<u> </u>	Ŏ	0	O O	<u> </u>	0	Ŏ	Ŏ	Ŏ	0
		LC-32GS20	200	200	0	0	0	<u> </u>	0	0	0	0	0	0	0	0	0
		LC-32GX5	300	300	0	0	<u> </u>	0	0	0	0	0	<u> </u>	0	0	0	0
		LC-32H7	100	100	0	0	0	<u> </u>	0	0	0	0	0	0	0	0	0
		LC-32H9	100 100	100	0	0	0	<u> </u>	0	0	0	0	0	0	0	0	0
		LC-32H10	100	100	0	0		<u> </u>	0	0	0	0	0	0	0	0	0
		LC-32H11 LC-32H20	100	100	0	0	0	0	0	0	0	0	0	0	0	0	0
		LC-32H2U LC-32J9	100	100	0	0	0	0	×	00	0	0	×	0	0	×	×
		LC-32J9 LC-32J10	100	100	0	0	0	$\frac{\circ}{\circ}$	Ô	00	0	0	ô	0	0	ô	Ô
1	I	LU 32010	100	100													

J_+_	サイズ(型)	型式	ネジウ	寸法													
ノーカー			W	Н	TV-PL3	CR-PL6N	CR-PL7	CR-PL11N	TV-PL12K	CR-PL13N	CR-PL14N	CR-PL16N	CR-PLKG1	CR-PLKG2	CR-PLKG3	YK-PLKG5	YK-PLKG6
		LC-32P1	300	300	0	0	0	0	0	0	0	0	0	0	0	0	0
		LC-32R5	200	200	× ×	0	×	0	××	0	0	0	××	0	0	0	0
		LC-32SC1	200	200	0	0	0	0	0	0	0	0	0	0	0	0	0
		LC-32V5	200	200	0	0	0	0	0	0	0	0	0	0	0	0	0
		LC-32V7	200	200	0	0	0	0	×	0	0	0	0	0	0	0	0
		PN-325	200	200	0	0	0	0	0	0	0	0	0	0	0	0	0
		PN-K321	200	200	0	0	0	0	0	0	0	0	0	0	0	0	0
		PN-K322B	200	200	0	0	0	0	0	0	0	0	0	0	0	0	0
		PN-T321	200	200	0	0	0	0	0	0	0	0	0	0	0	0	0
		PN-T322	200	200	0	0	0	0	0	0	0	0	0	0	0	0	0
		PN-T322B	200	200	0	0	0	0	0	0	0	0	0	0	0	0	0
		PN-Y325	200	200	0	0	0	0	0	0	0	0	0	0	0	0	0