

メーカー	サイズ(型)	型式	ネジ穴寸法		TV-LAST6	CR-LAST7	YK-TV004シリーズ	CR-PL13	CR-PL17	CR-PLKG2	YK-PLKG5	
			W	H								
TOSHIBA	37	37A2	-	-	×	×	×	×	×	×	×	
		37C8000	200	200	○	○	○	○	×	○	○	
		37H1	200	200	○	○	○	○	×	○	○	
		37HE1	200	200	○	○	○	○	×	○	○	
		37H8000	200	200	○	○	○	○	×	○	○	
		37R1	200	200	○	○	○	○	×	○	○	
		37RE1	200	200	○	○	○	○	×	○	○	
		37RH500	200	200	○	○	○	○	×	○	○	
		37Z1	200	200	○	○	○	○	×	○	○	
		37Z1S	200	200	○	○	○	○	×	○	○	
		37Z2	200	200	○	○	○	○	×	○	○	
		37Z3	200	200	○	○	○	○	×	○	○	
		37ZS1	200	200	○	○	○	○	×	○	○	
		37Z8000	200	200	○	○	○	○	×	○	○	
		37Z9000	200	200	○	○	○	○	×	○	○	
		37Z9500	200	200	○	○	○	○	×	○	○	
		37Z9500	200	200	○	○	○	○	×	○	○	
	37ZP3	200	200	○	○	○	○	×	○	○		
	32	32A1	-	-	×	×	×	×	×	×	×	×
		32A2	200	200	○	○	○	○	×	○	○	
		32AE1	200	200	○	○	○	○	×	○	○	
		32A1S	-	-	×	×	×	×	×	×	×	×
		32A8000	200	200	○	○	○	○	×	○	○	
		32A9000	200	200	○	○	○	○	×	○	○	
		32A900S	200	200	○	○	○	○	×	○	○	
		32A950S	200	200	○	○	○	○	×	○	○	
		32AC4	-	-	×	×	×	×	×	×	×	×
		32AS2	200	200	○	○	○	○	×	○	○	
		32B3	200	200	○	○	○	○	×	○	○	
		32BC3	200	100	○	○	○	○	×	○	○	
		32BE3	200	200	○	○	○	○	×	○	○	
		32C8000	200	200	○	○	○	○	×	○	○	
		32H1S	200	200	○	○	○	○	×	○	○	
32H8000		200	200	○	○	○	○	×	○	○		
32H9000	200	200	○	○	○	○	×	○	○			
32HB2	200	200	○	○	○	○	×	○	○			
32HE1	200	200	○	○	○	○	×	○	○			
32G9	200	200	×	×	×	○	×	○	○			
32J7	200	100	○	○	○	○	×	○	○			
32R1	200	200	○	○	○	○	×	○	○			
32R1BDP	200	100	○	○	○	○	×	○	○			

メーカー	サイズ(型)	型式	ネジ穴寸法		TV-LAST6	CR-LAST7	YK-TV004シリーズ	CR-PL13	CR-PL17	CR-PLKG2	YK-PLKG5	
			W	H								
	29	32R3	200	200	○	○	○	○	×	○	○	
		32R9000	200	200	○	○	○	○	×	○	○	
		32RB2	200	200	○	○	○	○	×	○	○	
		32RE1	200	200	○	○	○	○	×	○	○	
		32RE2	200	200	○	○	○	○	×	○	○	
		32RX1	200	200	○	○	○	○	×	○	○	
		32S5	200	200	○	○	○	○	×	○	○	
		32S7	200	200	○	○	○	○	×	○	○	
		32S8	200	200	×	×	×	○	×	○	○	
		32ZP2	200	200	○	○	○	○	×	○	○	
		32ZS1	200	200	○	○	○	○	×	○	○	
		29S7	200	100	○	○	○	○	×	○	○	
		26	26A1	200	100	○	○	○	○	×	○	○
	26A2		200	100	○	○	○	○	×	○	○	
	26B3		200	100	○	○	○	○	×	○	○	
	26HE1		200	100	○	○	○※	○	×	○	○	
	26R1BDP		100	100	○	○	○※	○	×	○	○	
	26RB2		200	100	○	○	○	○	×	○	○	
	26RE1		200	100	○	○	○	○	×	○	○	
	26RE1S		200	100	○	○	○	○	×	○	○	
	26RE2		200	100	○	○	○※	○	×	○	○	
	26RS2		200	100	○	○	○※	○	×	○	○	
	26R3		200	100	○	○	○	○	×	○	○	
	26ZP2	100	100	○	○	○※	○	×	○	○		
	24	24B5	100	100	○※	○※	○※	○	×	○	○	
	23	23S7	100	100	○※	○※	○※	○	×	○	○	
		23S8	100	100	×	×	○※	○	×	○	○	
	22	22A1	100	100	○※	○※	○※	○	×	○	○	
		22A2	100	100	○※	○※	○※	○	×	○	○	
		22B3	100	100	○※	○※	○※	○	×	○	○	
		22AC2	100	100	○※	○※	○※	○	×	○	○	
		22HE2	確認中						×			
		22RE1	100	100	○※	○※	○※	○	×	○	○	
		22RE2	100	100	○※	○※	○※	○	×	○	○	
		22RS2	100	100	○※	○※	○※	○	×	○	○	
	22R3	100	100	○※	○※	○※	○	×	○	○		

※…背面部の端子が隠れる部分があります。

…付属のワッシャーでの取付け不可。別途ワッシャー(外径20~30mm)が必要